
CLSC15 SURFACE CLOSER INSTALLATION INSTRUCTIONS—

Verify closer spring size

"Spring size chart".


Tools recommended

- Drill Bits Metal: 3/16" [#12]
- Wood: 5/32" [#22]
- #2 Phillips screwdriver
- 1/2" or 13mm box wrench
- 10" adjustable wrench
- 4mm hex kev



Verify the swing of the door

Make sure door operates efficiently prior to which is being installed prior installation. to installation.





Technical specifications

Spring size chart

Closer is shipped at a size 3 from factory.

Regular & top jamb closers			Parallel arm closers		
Maximum size of door width			Maximum size of door width		
Closer size	Interior	Exterior	Interior	Exterior	# Turns from size 3
1	28"				12 CCW
2	34"	28"	28"		6 CCW
3	38"	30"	34"	28"	0 turns
4	48"	36"	38"	30"	9 CW
5	54"	42"	48"	36"	13 CW





- 1.1 Adjust the spring size for the door width listed in the corresponding "spring size chart". Closer is set at size 3 from the factory.
- Increase spring size: Turn full 360° turns clockwise
- Decrease spring size: Turn full 360° turns counter-clockwise
- 1.2 Adjust the sweep (closing & latch) speed from 90° to 10°
- Increase speed: Turn valve counterclockwise


- Decrease speed: Turn valve clockwise.
- 1.3 Adjust the latch speed for 10° 0°.
- 1.4 Adjust the backcheck starting at 70°.
- Increase resistance: Turn valve clockwise Decrease resistance: Turn valve counter-

Do not back valves out beyond closer casting.


M Use a 4mm hex key


Door should close in 3 to 6 seconds from

clockwise.



- 1.1 Lay retaining clip on pinion, open side toward door.
- 1.2 Slide cover over closer body and snap onto retaining clip.
- **1.3** Slide dust cap over bearing housing.







NOTE: Orient spring side away from the hinge.


Refer to regular mount template for drill hole dimensions.

1.1 Secure closer body to door.


Use four #14 x 1-1/2" wood screws [1/4" x 1-1/2" self-tapping flat head screws1










- Loosen hold open nut.
- Open door 10° before desired hold open position.
- Tighten hold open nut securely.
- **1.3** To disengage hold open: Pull/push door closed until hold open releases and closer takes over.










Friction

hold open




Use four #14 x 1-1/2" wood screws

[1/4" x 1-1/2" self-tapping flat head

[1/4" x 1-1/4" self-tapping round head

screwsl



Use pinion screw and toothed

NOTE: Be sure main arm is parallel

to door: towards the latch.

lock washer

valve locations.)

2

2.4 To apply pre-load: Place wrench on

lower pinion and rotate, towards

hinge, until wench is 45° to door.

